


EXTENDED SYMPTOM CODE (*) THE 'X' EXTENDED SYMPTOM CODES (*-**X) SHOULD ONLY BE USED TO INDICATE THAT A SUITABLE SYMPTOM DESCRIPTION IS NOT AVAILABLE IN THE CONCERNED SYMPTOM GROUP

Symptomtable

www.iriscode.org



CONDITION CODE	MAIN SYMPTOM CODE	1 - NO ACTION	2 - LEVEL	3 - QUALITY	4 - NOISE	5 - UNSTABLE	6 - RECORDING & PHYSICAL PROBLEMS	7 - SPECIAL FUNCTIONS	8 - OTHER CONDITIONS	9 - SPECIAL CATEGORIES
1	Constantly									
2	Intermittently									
3	After a while									
4	In a hot environment									
5	In a cold environment									
6	When switching									
7	Under vibration									
8	In a damp / wet / rainy / snowy environment									
9	In a dry environment									
A	Due to physical damage									
B	After lightning strike									
C	Only certain station(s) / software / mode / channels / frequency band / network(s)									
D	Only on certain standards or systems									
E	Only on one channel									
F	Only with certain input(s)									
G	Only on certain output(s)									
H	In standby / idle / off mode									
I	At switch-on									
J	At edit point									
K	When interconnected, used with specific external equipment, adapter kit									
L	Liquid contamination									
M	For a short while after switch-on									
N	After making a copy									
O	Under stressed conditions / high load									
P	At switch-off									
Q	Only while sending / writing									
R	Only while receiving / reading									
S	Only with certain media									
T	Only when accessing a specific area of the medium									
U	Only at certain geographical location(s)									
V	After product update / upgrade									
X	Extended IRIS code line (advanced)									
		110 - Power problem or not operating 111 - No power 112 - No power when using AC adapter 113 - No power when using dry batteries 114 - No power when using rechargeable batteries 115 - No power from solar cell 116 - No power when using a car battery 117 - Short operation time / short battery life 118 - Power-off function not working 119 - No switch-on from standby 11A - Powers up but no operation 11B - Cyclic power on / off 11C - Blowing external (mains) fuse 11D - Set switches off by itself 11E - Backup battery problem 11F - Not operating 11G - No automatic switch on / off 11H - Internal protection switch / fuse in set triggers 11J - Battery not recognized 11K - Set start-up too slow 11X - Other "power problem or not operating" problem 11L - Set switches ON by itself 11M - Set reboots / restarts itself unexpectedly	120 - Charging problem / Level problem 121 - No battery charging 122 - Incomplete battery charge 123 - Charging time too long 124 - Insufficient heating / temperature (not specific) 125 - Excessive heating / temperature (not specific) 126 - Insufficient cooling (not specific) 127 - Excessive cooling (not specific) 128 - Wireless charging malfunction 12X - Other charging problem	130 - Display function problem 131 - No or faulty display 132 - Faulty lamp / LED operation 133 - Faulty level meter operation 134 - No or faulty on-screen display operation 135 - Electronic tuning display fault 136 - Mechanical tuning display fault 137 - Faulty time code display 138 - Faulty alarm / error display 139 - Display dim / too dark / partial / flickering / bad colour etc. 13A - Unusual or incorrect message in display 13B - No, partial, or uneven backlight 13C - Acoustic signal, no display 13D - Warning light does not work 13E - Warning light lights up 13F - Missing segment(s) 13G - Problem with ambient light 13X - Other display function problem	140 - Abnormal noise 141 - CRT discharging noise 142 - EHT discharging noise 143 - Noisy cabinet / cracking trays 144 - Noisy transformer / humming 145 - Noisy component(s) 146 - Rattle 147 - Clicking 148 - Clock noise 149 - Cracking 14A - Whistling 14B - Bubbling, boiling 14C - Muzzling 14D - Gurgling 14E - Sizzling 14F - Squealing 14G - Grinding 14H - Rumbling 14I - Pumping noise 14X - Other "abnormal noise" problem	150 - Remote control problem 151 - No remote control operation 152 - Incorrect remote control operation 153 - Remote control programming / learning mode problem 154 - Poor remote control sensitivity 155 - Remote operation problem via Mobile device APP 156 - Remote operation problem via Bluetooth 157 - Remote operation problem via WIFI 158 - Mobile device APP poor / unstable / too slow connection to main unit 159 - Mobile device APP crashes / impossible to connect 15X - Other remote control problem	160 - Physical damage 161 - Damaged / deformed cabinet / panel / glass 162 - Damaged handle / Clip / transport strap 163 - Damaged control knob(s) / button(s) / keypad 164 - Damaged door / cover 165 - Damaged seal 166 - Damaged plug / socket / terminal / connector / card holder 167 - Damaged lens 168 - Damaged cartridge or stylus 169 - Damaged antenna 16A - Damaged CRT / viewfinder / LCD display 16B - Missing component(s) or ornamental part(s) 16C - Printed markings erased / peeled off 16D - Set burning / emits smoke 16E - External surface damage (bubbling / peeling / rusting / scratched / sharp edges) 16F - Smell 16G - Weak / damaged stand 16H - Damaged speaker 16J - Set gets very hot / parts melting 16K - Foreign substance on / in unit 16L - Burning marks 16M - Internal surface damage (bubbling / peeling / rusting / scratched) 16N - Damaged power cable 16P - Damaged accessory 16R - Discolouration 16S - Consumer hurt 16T - Damaged / defect filter 16U - Packaging 16X - Other physical damage 16V - Wrinkled Display	170 - General function problem 171 - Faulty clock function 172 - Faulty sleep function 173 - Faulty timer programming 174 - Faulty timer operation 175 - Programming / user adjustment problem 176 - Faulty record mute operation 177 - Faulty programmed playback operation 178 - Faulty memory function 179 - Faulty input switching 17A - Faulty output switching 17B - Electric shock / static discharge 17C - Faulty search function (index / view / title / chapter / track ...) 17D - Wrong language / character set 17E - Error code / signal appears in display 17F - Switch / keypad / regulator not operating 17G - Pedal not operating 17H - Faulty standby mode 17J - Faulty hibernation mode 17K - No audible warning signal 17L - Faulty operation of parental lock / keylock function 17M - Faulty mode switching 17N - Menu function problem 17O - No interior lighting 17P - Faulty user control function 17Q - Faulty flashlight / lamp operation 17R - Region-code / security-related problem (DVD a.o.) 17S - Temperature not adjustable 17T - Program blocked 17U - Faulty steam 17V - Not weighing 17W - Accessory doesn't work 17X - Other general function problem	180 - Special requirements 181 - Test and check 182 - General overhaul 183 - System / frequency conversion 184 - Initial setup / installation requested 185 - Modification / circuit / installation change 186 - Wrong product in carton 187 - Wrong or missing accessory 188 - Unable to connect parts / to assemble 189 - Wrong colour 18A - Colour mismatch 18B - Battery mounting problem 18C - Software / Firmware upgrade requested 18D - Set causes malfunctions in other sets 18E - Calibration / alignment requested 18X - Other special requirements 18Z - Symptom not available	190 - Smell 191 - Burning smell 192 - Greasy smell 193 - Rubber smell 194 - Rotten / waste water smell 195 - Plastic smell 196 - Chlorine smell 197 - Purifier smell 198 - Gas smell 199 - Ammonia smell 19A - Fuel / oil smell 19B - Soot smell 19X - Other specific "smell" problem
		210 - No reception or connection 211 - No AM reception 212 - No FM reception 213 - No SW reception 214 - No VHF reception 215 - No UHF reception 216 - No BS reception 217 - No CS reception 218 - No HDTV reception 219 - No GPS / QPS reception 21A - No reception of digital broadcasting 21B - No IR reception 21C - No dial tone 21D - No modem / telephone / fax connection 21E - Modem / telephone not answering / no carrier 21F - No network / Internet connection / network initialization fails 21X - Other no reception problem	220 - Poor reception or connection 221 - Poor AM reception 222 - Poor FM reception 223 - Poor SW reception 224 - Poor VHF reception 225 - Poor UHF reception 226 - Poor BS reception 227 - Poor CS reception 228 - Poor HDTV reception 229 - Poor GPS / QPS reception 22A - Poor reception of digital broadcasting 22B - Poor IR reception 22C - Poor / interrupted Internet / Network connection 22X - Other poor reception problem	230 - Transmission / connection problem 231 - No transmission / connection 232 - Poor transmission / connection 233 - Transmission level too high 234 - No transmission between base unit and handset 235 - Poor transmission between base unit and handset 236 - No IR transmission 237 - One-sided connection 238 - Modem / telephone hangs up immediately once connected 239 - Modem / telephone drops line during connection 23A - No or faulty transmission confirmation / logging 23X - Other transmission / connection problem	240 - Noisy reception / transmission 241 - Line noise 242 - Oscillation 243 - Interstation interference 24X - Other noisy reception / transmission problem	250 - Unstable reception / transmission 251 - Tuning drift 252 - Fading 253 - Intermittent line / line breaking off 254 - No or unstable connection combined with "weak signal strength" indication 25X - Other unstable reception / transmission problem	260 - Tuning / Navigation problem 261 - Manual tuning problem 262 - Automatic tuning problem 263 - Incorrect tuning 264 - Tuning memory / Phonebook / Address book problem 265 - Vehicle position different from map data 266 - Wrong map data 267 - Map not displayed 268 - Vehicle position does not move or moves when it should not 269 - Cannot search by entered criteria 26A - Problem to calculate desired route 26B - Auto reroute does not work 26C - No or too slow traffic info display 26X - Other tuning / navigation problem	270 - Special communication problem 271 - Faulty dialling 272 - Automatic channel selection 273 - Faulty auto-answer operation 274 - Faulty message read-out function 275 - Faulty autodial / redial memory 276 - Faulty speech processing / No voice (control) recognition 277 - No ringing tone / vibration 278 - Loud / weak ringing tone 279 - Modem / telephone stuck off hook 27A - Fax does not work properly 27B - Modem causes problem with phone 27C - No modem / telephone dial tone 27D - Call transfer problem 27E - Report / Journal function problem 27F - Faulty Video phone / conference function 27X - Other special communication problem	280 - Special reception problem 281 - Faulty stereo reception 282 - Faulty main channel (A) function 283 - Faulty sub-channel (B) function 284 - Faulty SSB reception 285 - Faulty RDS / VPS / PDC / XDS operation 286 - Faulty teletext / close caption / EPG reception 287 - Faulty satellite / RTTY reception 288 - Faulty fax operation 289 - Modem not recognized by system 28A - Faulty call charge / call time function 28B - Faulty hands-free operation 28C - Set locked 28D - Faulty antenna control 28X - Other special reception problem 28E - Faulty Subtitle function	
		310 - No picture 311 - No picture in E to E mode 312 - No picture in playback mode 313 - No picture in viewfinder 314 - No picture / only raster 315 - No raster / black picture 316 - Horizontal line (bar) problem 317 - Vertical line (bar) problem 318 - No picture in LCD 319 - No 2nd (or higher) monitor display 31X - Other no picture problem	320 - Picture level problem 321 - Picture too dark 322 - Picture too bright 323 - Contrast too low 324 - Contrast too high 325 - Saturated white or black level 326 - Shading on picture 327 - Only partial picture 328 - Solarization effect on picture 32X - Other picture level problem	330 - Picture quality problem 331 - Poor picture resolution 332 - Poor focus 333 - Ringing on picture 334 - Excessive smear / lag 335 - Poor linearity or geometry 336 - Picture size incorrect 337 - Incorrect centring of picture 338 - Picture slanted 339 - V-size incorrect 33A - H-size incorrect 33B - Ghosting in 3D Mode 33X - Other picture quality problem	340 - Picture noise 341 - Snowy picture 342 - Dot noise or dropout on picture 343 - Noise bars on picture 344 - Blanking lines on picture 345 - Beating on picture 346 - Ghosting on picture 347 - VCR head switching noise on picture 348 - Overmodulation noise 349 - Moiré 34A - Mosaic noise 34B - Scrambled picture 34C - Clouthing, "MURA" 34X - Other picture noise problem	350 - Unstable picture 351 - Sync problem 352 - Picture pumping 353 - Picture jitter 354 - Picture shaking (horizontal or vertical) 355 - Flickering picture 356 - Flashing picture 357 - Cyclic picture muting 358 - Head impact error causing unstable picture 359 - VCR skew / H-shift error 35A - Freezing picture / Display 35B - Jumping / repeating picture 35X - Other unstable picture problem	360 - Poor picture / video recording 361 - No picture / video recording 362 - No erasure protection for video 363 - Previous video recording not being erased 364 - Unwanted erasure of picture 365 - No camera recording 366 - Only one field per frame being recorded 367 - Records only a few pictures 368 - Built-in Camera problem / defect 36X - Other picture recording problem	370 - Special picture function problem 371 - Editing problem 372 - Faulty fading / wiper operation 373 - Faulty negative / positive switching function 374 - Faulty superimpose / telop operation 375 - Faulty Picture in Picture / digital picture operation 376 - Faulty picture transmission 377 - Faulty digital shutter function 378 - Faulty genlock function 379 - Faulty flash / strobe function 37A - Faulty digital picture / zooming function 37B - Faulty auto-edit function 37C - Faulty picture stabilizer function 37D - Faulty picture capture function 37E - Faulty subtitling function 37F - Faulty variable speed playback 37G - Faulty view / multi-angle switching 37H - Faulty aspect ratio switching 37J - Thumbnail or index picture problem 37K - No blanking screen 37L - Faulty low light function 37M - Faulty picture format conversion 2D<->3D 37X - Other special picture function problem	380 - Picture display / CCD-Sensor problem 381 - Burn mark on display / CCD-Sensor 382 - Scratch on display / CCD-Sensor 383 - Dust / dirt on display / CCD-Sensor 384 - Phosphor / pixel missing on display / CCD-Sensor 385 - Bright, dark, or flashing pixels 386 - Lines across / down image 387 - Out of specs pixel defaults 388 - Background burnt in 389 - One or more bright or dark lines 38A - Abnormal light emission of the display 38X - Other picture display / CCD-Sensor problem	
		410 - No colour 411 - No colour in E to E mode 412 - No colour in playback mode 413 - No colour in viewfinder 414 - No colour in part of picture 41X - Other no colour problem	420 - Colour level problem 421 - Weak colour 422 - Excessive colour 42X - Other colour level problem	430 - Poor colour quality 431 - Some or all colours missing 432 - Poor white balance 433 - Hue problem 434 - Purity error 435 - Landing error / white uniformity 436 - Convergence error 437 - Registration error 438 - Pitch moiré / rainbow pattern 439 - Colour shift 43X - Other colour quality problem	440 - Noisy colour 441 - Colour noise on a black & white picture 442 - Colour streaking 443 - Colour bars on picture 44X - Other colour noise problem	450 - Unstable colour 451 - Colour flashing 452 - Hue constantly changing 453 - Flickering colour 454 - Colour not locked 45X - Other unstable colour problem	460 - Poor colour recording 461 - No colour recording 462 - Noisy colour recording 46X - Other colour recording problem	470 - Special colour function problem 471 - Faulty automatic white balance 472 - Faulty colour effects function 47X - Other special colour function problem		




EXTENDED SYMPTOM CODE (*1) THE 'X' EXTENDED SYMPTOM CODES (*-**X) SHOULD ONLY BE USED TO INDICATE THAT A SUITABLE SYMPTOM DESCRIPTION IS NOT AVAILABLE IN THE CONCERNED SYMPTOM GROUP

Symptomtable

www.iriscode.org



1	2	3	4	5	6	7	8	9	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	X
1 - NO ACTION		2 - LEVEL		3 - QUALITY		4 - NOISE		5 - UNSTABLE		6 - RECORDING & PHYSICAL PROBLEMS		7 - SPECIAL FUNCTIONS		8 - OTHER CONDITIONS		9 - SPECIAL CATEGORIES															
5		AUDIO		<p>510 - No audio</p> <p>511 - No sound in E to E mode</p> <p>512 - No playback of outgoing message(s) (OGM)</p> <p>513 - No playback of incoming message(s) (ICM)</p> <p>514 - No audio playback</p> <p>515 - No sound from handset</p> <p>516 - No sound from speaker</p> <p>517 - No sound from earphone / headphone</p> <p>518 - No microphone sound</p> <p>519 - No sound from digital output</p> <p>51X - Other no audio problem</p>		<p>520 - Audio level problem</p> <p>521 - Low audio level</p> <p>522 - Excessive audio level</p> <p>523 - Balance problem</p> <p>524 - Fader problem</p> <p>525 - Audio level remaining / no muting</p> <p>52X - Other audio level problem</p>		<p>530 - Audio quality</p> <p>531 - Poor frequency response</p> <p>532 - Distorted audio</p> <p>533 - No or poor treble</p> <p>534 - No or poor bass</p> <p>535 - Earphone / headphone audio poor</p> <p>536 - Audio delay / lip-sync problem</p> <p>53X - Other audio quality problem</p>		<p>540 - Noisy audio</p> <p>541 - Hum</p> <p>542 - Hiss / rustle / background noise</p> <p>543 - Crosstalk</p> <p>544 - Static / pop or click noise</p> <p>545 - Buzz, noise from picture display or deflection</p> <p>546 - Scratching noise</p> <p>547 - Ignition noise</p> <p>548 - Whistling / multipath noise</p> <p>549 - Data / digital noise</p> <p>54X - Other audio noise problem</p>		<p>550 - Unstable audio</p> <p>551 - Jumping or repeating audio</p> <p>552 - Audio pumping or breathing</p> <p>553 - Audio dropouts</p> <p>554 - Cyclic audio muting</p> <p>555 - Wow and flutter</p> <p>556 - Howling / acoustic feedback</p> <p>557 - Echo in sound</p> <p>55X - Other unstable audio problem</p>		<p>560 - Poor audio recording</p> <p>561 - Audio not being recorded</p> <p>562 - No erasure protection for audio</p> <p>563 - Previous audio recording not being erased</p> <p>564 - Unwanted erasure of audio</p> <p>565 - Message not being recorded</p> <p>566 - Distorted audio recording</p> <p>56X - Other audio recording problem</p>		<p>570 - Poor special audio function</p> <p>571 - Faulty fade operation</p> <p>572 - Faulty echo operation</p> <p>573 - Faulty mixing operation</p> <p>574 - Faulty repeat mode operation</p> <p>575 - Faulty audio processing</p> <p>576 - Faulty sync recording operation</p> <p>577 - Faulty DBB / DDL operation</p> <p>578 - Faulty noise reduction operation</p> <p>579 - Faulty audio dub function</p> <p>57A - Faulty title programming</p> <p>57B - Faulty microphone control</p> <p>57C - Faulty pitch control</p> <p>57X - Other special audio function problem</p>		<p>580 - Stereo / multi-mode operation</p> <p>581 - No stereo operation</p> <p>582 - Poor channel separation</p> <p>583 - Difference in phase between channels</p> <p>584 - Problem with surround sound mode</p> <p>585 - Problem with PCM audio mode</p> <p>586 - Problem with compressed digital audio data</p> <p>58X - Other stereo / multi-mode problem</p>													
6		MECHANISM		<p>610 - No mechanical operation</p> <p>611 - No rotation of motor / disc / swivel</p> <p>612 - No forward operation</p> <p>613 - No reverse operation</p> <p>614 - No fast forward or rewind function</p> <p>615 - No loading</p> <p>616 - No unloading or ejecting</p> <p>617 - No auto shut-off operation</p> <p>618 - Tonearm does not move</p> <p>619 - Disc not being ejected</p> <p>61A - Magazine or module loading / unloading</p> <p>61B - Control / switch not working</p> <p>61C - Open / close problem of door / panel / drawer / tray</p> <p>61D - No fan / ventilation</p> <p>61X - Other no mechanical operation problem</p>		<p>620 - Irregular mechanical operation</p> <p>621 - Irregular rotation</p> <p>622 - Irregular forward mode</p> <p>623 - Irregular reverse operation</p> <p>624 - Irregular fast forward or rewind function</p> <p>625 - Irregular loading of media</p> <p>626 - Irregular unloading or ejecting</p> <p>627 - Irregular auto shut-off operation</p> <p>628 - Irregular tonearm movement</p> <p>629 - Irregular ejection of disc</p> <p>62A - Irregular direction change</p> <p>62B - Faulty disc change operation</p> <p>62C - Faulty automatic cord rewinder</p> <p>62X - Other irregular mechanical operation problem</p>		<p>630 - Speed problem</p> <p>631 - Speed too fast</p> <p>632 - Speed too slow</p> <p>633 - Speed unadjustable</p> <p>63X - Other speed problem</p>		<p>640 - Mechanical noise</p> <p>641 - Rotation noise / drum noise</p> <p>642 - Motor noise</p> <p>643 - Wind / air noise</p> <p>644 - Squealing</p> <p>645 - Fan noise</p> <p>646 - Disc scraping</p> <p>647 - Noisy tape loading</p> <p>648 - Gear noise</p> <p>649 - Control or switch noisy</p> <p>64A - Grinding</p> <p>64B - Rumbling</p> <p>64C - Vibration noise</p> <p>64D - Noise from lens mechanism</p> <p>64X - Other mechanical noise problem</p>		<p>650 - Mechanical instability</p> <p>651 - Uneven feet</p> <p>652 - Faulty hinge</p> <p>653 - Vibrating / jumping</p> <p>654 - Part(s) loose</p> <p>655 - Wheel defect</p> <p>656 - Poor handset / cradle position</p> <p>657 - Leakage general</p> <p>658 - Waterproof problem</p> <p>65X - Other mechanical instability problem</p>		<p>660 - Damage to media</p> <p>661 - Tape gets scratched</p> <p>662 - Disc gets scratched</p> <p>663 - Tape gets chewed / wrinkled</p> <p>664 - Tape jammed or broken</p> <p>665 - Tape gets curled</p> <p>666 - Slack tape</p> <p>667 - Tape sticking</p> <p>66X - Other software damage problem</p>		<p>670 - Mechanical operation problem</p> <p>671 - Faulty start / stop / braking operation</p> <p>672 - Faulty pause operation</p> <p>673 - Faulty automatic program search</p> <p>674 - Faulty cue / review mode</p> <p>675 - Faulty slow motion operation</p> <p>676 - Faulty high-speed scanning mode</p> <p>677 - Faulty speed copy function</p> <p>678 - Faulty repeat operation</p> <p>679 - Faulty record review mode</p> <p>67A - Faulty AMS operation</p> <p>67B - Auto-reverse malfunction</p> <p>67C - Faulty end detection</p> <p>67D - Faulty disc slide (A-B select) switching</p> <p>67X - Other mechanical operation problem</p>		<p>680 - Lens problem</p> <p>681 - Focus problem</p> <p>682 - Zoom problem</p> <p>683 - Iris problem</p> <p>684 - Macro problem</p> <p>685 - Foreign substance / dust inside lens</p> <p>68X - Other lens problem</p>		<p>690 - Damaged door / lid</p> <p>691 - Damaged door panel</p> <p>692 - Damaged freezer compartment lid</p> <p>693 - Door does not close properly</p> <p>694 - Door cannot be opened / heavy to open</p> <p>695 - Damaged door gasket</p> <p>696 - Damaged door frame</p> <p>697 - Damaged door glass</p> <p>698 - Door falls off</p> <p>699 - Faulty door switch</p> <p>69A - Door slanted</p> <p>69B - Damaged hinge</p> <p>69C - Malfunctioning door locking device</p> <p>69D - Noise when opening / closing door</p> <p>69X - Other "damaged door / lid" problem</p>											
7		DATA PROCESSING		<p>710 - No data processing operation</p> <p>711 - No initial screen</p> <p>712 - System does not reset</p> <p>713 - System does not boot up</p> <p>714 - No operation from plug-in module / peripheral</p> <p>715 - No keyboard operation</p> <p>716 - No operation from other input / output device</p> <p>717 - No data storage operation</p> <p>718 - No data communication</p> <p>719 - Error message display</p> <p>71A - HDD boot failure</p> <p>71B - FDD boot failure</p> <p>71C - CD/DVD disc boot failure</p> <p>71D - Operation process freezing</p> <p>71X - Other no data processing problem</p>		<p>720 - Faulty data processing operation</p> <p>721 - Incorrect data</p> <p>722 - Operating system reset / crashes while being used</p> <p>723 - Operating system locks out / crashes / hangs while idle / Standby</p> <p>724 - Faulty operation of plug-in module, memory card, etc.</p> <p>725 - Faulty keyboard operation</p> <p>726 - Faulty operation of other input / output device</p> <p>727 - Faulty data storage operation</p> <p>728 - Faulty data communication / data synchronisation</p> <p>729 - Memory error</p> <p>72A - Requires setup at booting</p> <p>72B - Operating system boot-up only in safe mode</p> <p>72C - Operation control too slow / sluggish / freezing</p> <p>72E - Mobile payment malfunction</p> <p>72D - Operating system cannot be installed</p> <p>72X - Other faulty data processing problem</p>		<p>730 - Data display problem</p> <p>731 - Incorrect character display</p> <p>732 - Missing display characters</p> <p>733 - Faulty graphic display</p> <p>734 - Faulty switching between graphic / character mode</p> <p>735 - Faulty prompt / cursor operation</p> <p>736 - Data display colour incorrect</p> <p>737 - No paging or scroll mode</p> <p>738 - Does not display media titles or content</p> <p>739 - Incorrect values shown on display</p> <p>73X - Other data display problem</p>		<p>740 - Keyboard / pointing device / touchscreen</p> <p>741 - Mouse / trackball / trackpad / touchscreen not working</p> <p>742 - Keyboard / touchscreen locks up</p> <p>743 - Pointing device locks up</p> <p>744 - Sticky / hard to press key(s) / touchscreen</p> <p>745 - Inoperative key(s)</p> <p>746 - Pointing device / touchscreen not tracking properly / Sluggish</p> <p>747 - Pointing device / touchscreen jittery</p> <p>748 - Left or right click button inoperational</p> <p>749 - Trackpad / touchscreen surface damaged</p> <p>74A - Keyboard key(s) damaged</p> <p>74B - No keypad tone</p> <p>74C - Biomedical Sensor problem</p> <p>74D - Sensor problem for user authentication</p> <p>74E - Alert Sensor - false alarm</p> <p>74F - Alert Sensor - no or poor detection</p> <p>74X - Other keyboard / pointing device / touchscreen problem</p> <p>74G - Proximity Sensor problem</p>		<p>750 - Peripheral problem (non-storage)</p> <p>751 - Peripheral does not initialize</p> <p>752 - Communication failure with peripheral / IoT device</p> <p>753 - Internal peripherals failure</p> <p>754 - External peripherals failure</p> <p>755 - Network card error</p> <p>756 - Peripheral fails self test</p> <p>75X - Other peripheral problem</p>		<p>760 - Data storage problem</p> <p>761 - Formatting problem</p> <p>762 - Data on storage medium being lost</p> <p>763 - Frame memory problem</p> <p>764 - Read / write errors</p> <p>765 - Hard or optical disc drive problem</p> <p>766 - Floppy drive problem</p> <p>767 - CD / DVD-ROM drive problem</p> <p>768 - Tape problem</p> <p>769 - Medium not recognized / cannot access</p> <p>76A - Discs exchange problem</p> <p>76B - Read / write operation very slow</p> <p>76C - Memory card problem</p> <p>76D - SIM card problem</p> <p>76X - Other data read / write problem</p>		<p>770 - Special data processing function problem</p> <p>771 - Faulty self-diagnostic mode</p> <p>772 - Faulty word processing function</p> <p>773 - Faulty graphic edit function</p> <p>774 - Program / application cannot be installed</p> <p>775 - Preloaded program cannot be started up</p> <p>776 - Not preloaded program cannot be started up</p> <p>777 - Virus alarm</p> <p>778 - Messaging function problem / SMS / MMS</p> <p>779 - Application start-up cannot finalize</p> <p>77A - Application start-up slow</p> <p>77B - Software recovery problem</p> <p>77C - Password / access protection problem</p> <p>77D - Self-Diagnosis Reports pre-failure notice</p> <p>77X - Other special data function problem</p>		<p>780 - Interface problem</p> <p>781 - USB interface problem</p> <p>782 - Parallel interface problem</p> <p>783 - SCSI interface problem</p> <p>784 - Serial interface problem</p> <p>785 - Incompatible with other systems</p> <p>786 - Audio / video interface problem</p> <p>787 - i.Link / Firewire / IEEE1394 interface problem</p> <p>788 - LAN / Wifi problem</p> <p>789 - Docking station / port replicator / external device problem</p> <p>78A - Bluetooth / infrared problem</p> <p>78B - NFC problem</p> <p>78X - Other interface problem</p>													
8		PRINT / COPY / SCAN		<p>810 - No print / copy / scan operation</p> <p>811 - Not printing</p> <p>812 - No communication with printer</p> <p>813 - Paper not loading</p> <p>814 - No paper feed (internal function)</p> <p>815 - No image fixation</p> <p>816 - No document feeding</p> <p>817 - Scanner not working</p> <p>818 - No operation of paper feed module (external)</p> <p>819 - No Sorter/Finisher Function</p> <p>81X - Other no print / copy / scan problem</p>		<p>820 - Erroneous print / copy / scan operation</p> <p>821 - Print image reversed (negative / positive)</p> <p>822 - Irregular paper feed</p> <p>823 - Excessive print mode switching</p> <p>824 - Copy too dark</p> <p>825 - Copy too bright</p> <p>826 - Black copy</p> <p>827 - White copy</p> <p>828 - Poor colour levels</p> <p>829 - Irregular document feed</p> <p>82A - Faulty correction function</p> <p>82B - Poor scanning quality</p> <p>82X - Other print / copy / scan operation problem</p>		<p>830 - Poor print quality</p> <p>831 - Incorrect printing position</p> <p>832 - Low print contrast</p> <p>833 - Excessive print contrast</p> <p>834 - Blurred print image</p> <p>835 - Print image not sharp</p> <p>836 - Dots missing in print image</p> <p>837 - Colour streaking</p> <p>838 - No colour in part of image</p> <p>839 - Print image / copy incomplete</p> <p>83A - Faulty calibration</p> <p>83B - Ink Dripping / Splashing</p> <p>83X - Other print quality problem</p>		<p>840 - Noisy printing</p> <p>841 - Printing noise lines</p> <p>842 - Dirty printing</p> <p>843 - Unpleasant smell (ozone)</p> <p>844 - Black lines / stripes in feed direction</p> <p>845 - White lines / stripes in feed direction</p> <p>846 - Black lines / stripes across feed direction</p> <p>847 - White lines / stripes across feed direction</p> <p>84X - Other noisy printing problem</p>		<p>850 - Unstable printer operation</p> <p>851 - Unstable paper loading</p> <p>852 - Unstable multi-paper loading</p> <p>853 - Incorrect line-up of characters</p> <p>854 - Wrong detection of original document format</p> <p>85X - Other unstable printer operation problem</p>		<p>860 - Ribbon / paper problems</p> <p>861 - Ribbon broken</p> <p>862 - Ribbon stuck / sticking</p> <p>863 - Ribbon derailed</p> <p>864 - Paper stuck / sticking to mechanism</p> <p>865 - Paper jam</p> <p>866 - Document jam</p> <p>867 - Erroneous no ink / toner message</p> <p>868 - Faulty paper cutting function</p> <p>869 - Too short ink / toner lifetime</p> <p>86A - Paper skew / wrinkle / folding</p> <p>86B - Document skew / wrinkle / folding</p> <p>86X - Other ribbon / paper problem</p>		<p>880 - Faulty font / character functions</p> <p>881 - Incorrect characters or image</p> <p>882 - Incorrect character size</p> <p>883 - Font loading problem</p> <p>88X - Other faulty font / character function problem</p>															




EXTENDED SYMPTOM CODE (*1) THE 'X' EXTENDED SYMPTOM CODES (*-**X) SHOULD ONLY BE USED TO INDICATE THAT A SUITABLE SYMPTOM DESCRIPTION IS NOT AVAILABLE IN THE CONCERNED SYMPTOM GROUP

Symptomtable

www.iriscode.org



CONDITION CODE	MAIN SYMPTOM CODE	1 - NO ACTION	2 - LEVEL	3 - QUALITY	4 - NOISE	5 - UNSTABLE	6 - RECORDING & PHYSICAL PROBLEMS	7 - SPECIAL FUNCTIONS
1	Constantly							
2	Intermittently							
3	After a while							
4	In a hot environment							
5	In a cold environment							
6	When switching							
7	Under vibration							
8	In a damp / wet / rainy / snowy environment							
9	In a dry environment							
A	Due to physical damage							
B	After lightning strike							
C	Only certain station(s) / software / mode / channels / frequency band / network(s)							
D	Only on certain standards or systems							
E	Only on one channel							
F	Only with certain input(s)							
G	Only on certain output(s)							
H	In standby / idle / off mode							
I	At switch-on							
J	At edit point							
K	When interconnected, used with specific external equipment, adapter kit							
L	Liquid contamination							
M	For a short while after switch-on							
N	After making a copy							
O	Under stressed conditions / high load							
P	At switch-off							
Q	Only while sending / writing							
R	Only while receiving / reading							
S	Only with certain media							
T	Only when accessing a specific area of the medium							
U	Only at certain geographical location(s)							
V	After product update / upgrade							
X	Extended IRIS code line (advanced)							
	A	WASHING / DRYING						
	B	COOLING / HEATING / AIR CONDITIONING PORTABLE / FAN						
	C	COOKING						
	J	KITCHEN APPLIANCES / FOOD PROCESSING						
	K	PERSONAL CARE / HEALTH CARE / BABY CARE						
		1 - NO ACTION	2 - LEVEL	3 - QUALITY	4 - NOISE	5 - UNSTABLE	6 - RECORDING & PHYSICAL PROBLEMS	7 - SPECIAL FUNCTIONS
		A10 - No function A11 - No heating A12 - No water draining / pumping out A13 - No rinsing / no circulation A14 - No drying A15 - No salt consumption A16 - No clear rinse / softening agent consumption A17 - No detergent consumption A18 - No water inlet A19 - No air drain A1A - No water in container A1B - No spinning A1C - Stops during program flow A1D - Continues via stop A1E - Continues without stopping A1F - Program stops and pumps constantly A1G - Water inlet not stopped A1H - Heating up without water A1J - No water through flow / blockage A1K - No whitening agent consumption A1L - No softener consumption A1X - Other no function problem	A20 - Operational problem A21 - Pumping out improperly A22 - Insufficient water inlet A23 - Insufficient drying / spinning A24 - Excessive salt consumption A25 - Excessive clear rinse consumption A26 - Excessive detergent consumption A27 - Takes excessive water A28 - Program flow too fast / slow A29 - Water in soft rinsing chamber A2A - Improper spinning A2B - Program knob remains in every position A2C - Takes detergent only partially A2D - Takes softening agent immediately A2E - Water enters and drains off immediately A2G - Drying time too long A2H - Wrong drum positioning A2X - Other operational problem	A30 - Washing / cleaning poor performance A31 - Not clean A32 - Tea and coffee stains A33 - Lime deposits A34 - Food rests A35 - Granular deposits A36 - Dim and dull glasses A37 - Stripes / stains on tableware A38 - Rust on cutlery A39 - Wrinkled laundry A3A - Burnt laundry A3B - Laundry hot and dry A3C - Laundry hot and damp A3D - Laundry damaged A3X - Other "washing / cleaning poor performance" problem	A40 - Noise A44 - Spinning noise A4X - Other noise problem	A50 - Leakage and inlet / outlet damage A51 - Water leakage A52 - Steam emission A53 - Foaming A54 - Damaged hose A55 - Air emission A57 - Drum lid damaged / opened A58 - Drum blocked A59 - Condenser blocked A5X - Other leakage and inlet / outlet damage problem	A60 - Damaged parts A61 - Damaged tableware basket A62 - Damaged rinse aid chamber / cover A63 - Damaged detergent chamber / cover A64 - Damaged fluff filter A6X - Other damaged parts problem	
		B10 - No function B11 - No cooling B12 - No freezing B13 - No warming up B16 - No defrosting B17 - No dehumidification B19 - Ventilator does not switch off B1A - No ice production B1B - No crushed ice production B1C - No cold water production B1X - Other no function problem	B20 - Operational problem B22 - Insufficient freezing B26 - Excessive freezing B29 - Insufficient ventilation power B2A - Ventilation power only at one side B2B - Ventilation power not adjustable B2C - Compressor operating all the time B2D - Insufficient filter operation B2X - Other operational problem	B30 - Cooling / Heating poor performance B32 - Rotted / damaged food B33 - Ice cream too hard B34 - Insufficient ice cube quality B35 - Condensed water on food B3X - Other "cooling / heating poor performance" problem	B40 - Water / ice / noise problem B41 - Condensation inside cabinet B42 - Ice build up B44 - Water inside cabinet B45 - Noisy compressor B46 - Noisy magnet switch B47 - Noisy thermostat B4X - Other water / ice / noise problem	B50 - Leakage B51 - Fuel, Oil leakage B52 - Soot leakage B53 - Smoke emission B54 - Water leakage B5X - Other leakage problem	B60 - Damaged parts B61 - Damaged evaporator B62 - Temperature adjustment stuck B63 - Selection switch defective B64 - Filter holder defective B6X - Other damaged parts problem	
		C10 - No function C11 - Oven does not warm up C12 - Heating element does not work C13 - All hot plates do not work C14 - One hot plate does not work C15 - Hot plate extension does not work C16 - Hot air circulation defective C17 - Microwave section defective C18 - Grill defective C19 - No ignition C1A - No rotation of stirrer / deflector / antenna C1B - No rotation of turntable C1C - No heat residual indication C1D - No cleaning cycle C1E - Spit doesn't turn C1G - No pressure C1X - Other no function problem	C20 - Operational problem C21 - Uneven cooking C22 - Regulators do not work C23 - One regulator does not work C24 - Unstable / bad flames C25 - Insufficient heating up (hob / hot plate) C26 - Excessive heating up (hob / hot plate) C27 - Insufficient heating (oven) C28 - Excessive heating (oven) C29 - Cooking time too long C2A - Baking time too long C2B - Cooling fan running too long C2C - Flame goes out C2D - Insufficient cleaning C2E - Spit turns incorrectly C2F - Flashing / sparking visible C2X - Other operational problem	C30 - Cooking / Baking poor performance C31 - Bad cooking / baking performance C32 - Food burnt C33 - Uneven browning results C34 - Poor Microwave cooking C35 - Poor Grill cooking C36 - Poor Convection cooking C37 - Poor Steam cooking C38 - Poor cooking in combination mode C3X - Other "cooking / baking poor performance" problem		C50 - Leakage C51 - Heat emission / leakage C52 - Damp / condensation / dirt on door glass C53 - Gas leakage C54 - Microwave leakage C55 - Oil splash C5X - Other leakage problem	C60 - Damaged parts C61 - Defective cooking plate grid C62 - Hot plate slanted C63 - Damaged / stained / discoloured hob C64 - Oven ignition switch damaged C65 - Hot plate ignition switch damaged C66 - Oven switch / knob damaged C67 - Discoloured switch / knob C69 - Temperature sensor problem C6A - Damaged gas ignition device C6B - Damaged / discoloured cavity C6X - Other damaged parts problem	C70 - Gas circuit problems C71 - Gas hose damaged C72 - Gas socket damaged C73 - Pressure regulator damaged C74 - Gas cylinder damaged C75 - Gas / Service valve damaged C7X - Other gas circuit problem
		J10 - No function J11 - No kneading J12 - No blending J13 - No beating (beating whisk) J14 - No mixing J15 - No chopping J16 - No latching (rotary arm) J17 - No slicing J18 - No mincing J1X - Other "no function" problem	J20 - Operational problem J21 - Insufficient kneading J22 - Insufficient blending J23 - Insufficient beating (beating whisk) J24 - Insufficient mixing J25 - Insufficient chopping J26 - Insufficient latching (rotary arm) J27 - Insufficient slicing J28 - Insufficient mincing J29 - Handle malfunction J2X - Other "operational" problem	J30 - Poor performance / processing J31 - Bad baking / toasting performance J3X - Other "poor performance / processing"		J50 - Leakage J51 - Leakage of the bowl J52 - Leakage of jar J5X - Other "leakage" problem	J60 - Damaged parts J61 - Damaged rotary arm J62 - Damaged bowl J63 - Damaged basket J6X - Other damaged parts" problem	
		K10 - No function K11 - No heating K12 - No hot air circulation K13 - No measuring K14 - No reception or link K15 - No audio / video K1X - Other "no function" problem	K20 - Operational problem K21 - Insufficient air flow K22 - Cuff pressure too low K23 - Nozzle problem K24 - Oral irrigator problem K25 - Poor reception Audio / video K2X - Other "operational problem" K26 - ECG Electrocardiogram Sensor/Read Malfunction K27 - Blood Pressure Sensor/Read Malfunction	K30 - Poor care performance / results K31 - Incorrect weight K32 - Incorrect range / measurement units K33 - Bad shaving performance K34 - Bad cutting performance K35 - Poor auto clean function K36 - Blade worn-out K37 - Outer foil worn-out K38 - Hair is pulled K39 - Burning sensation (on skin) K3A - Enduser Pain K3B - Incorrect food mixing K3C - Bad measurement result K3D - Bad Sound K3E - Bad Video K3F - Interference K3X - Other "Poor care performance / result" problem				



EXTENDED SYMPTOM CODE (*1) THE 'X' EXTENDED SYMPTOM CODES (*-**X) SHOULD ONLY BE USED TO INDICATE THAT A SUITABLE SYMPTOM DESCRIPTION IS NOT AVAILABLE IN THE CONCERNED SYMPTOM GROUP

Symptomtable


www.iriscode.org



		1 - NO ACTION	2 - LEVEL	3 - QUALITY	4 - NOISE	5 - UNSTABLE	6 - RECORDING & PHYSICAL PROBLEMS	7 - SPECIAL FUNCTIONS						
1 2 3 4 5 6 7	L FLOOR CARE	L10 - No function L11 - Brush drive doesn't work L12 - No suction L1X - Other "no function" problem	L20 - Operational problem L21 - Floor nozzle problem L22 - Faulty Beater Brush operation L23 - Suction not adjustable L24 - Doesn't find base station (robot vacuum cleaner) L25 - No edge and stair recognition (robot vacuum clean) L2X - Other "operational problem"	L30 - Poor cleaning performance / results L31 - Bad cleaning performance L32 - Bad moving L33 - Insufficient suction L34 - Exhaust air too hot L3X - Other "poor cleaning performance / results" probl		L50 - Leakage L51 - Air leakage L52 - Water leakage L53 - Dust emission L5X - Other "leakage" problem	L60 - Damaged parts L61 - Dust bag defect L62 - Accessory locking problem L63 - Curve tube problem L64 - Drive belt damaged L6X - Other damaged parts" problem							
		A B C D E F G H I J	M GARMENT CARE	M10 - No function M11 - Pump doesn't work M12 - No spray (water or steam) M13 - No steam production M14 - Turbo function not working M15 - Steam selection does not work M1X - Other "no function" problem	M20 - Operational problem M21 - Insufficient steam pressure M22 - Too much steam M23 - Continuous steaming M24 - Too fast water consumption M25 - Handle too hot M26 - Hose too hot M27 - Insufficient ventilation M2X - Other "operational problem"	M30 - Ironing / poor performance M31 - Soleplate stuck M32 - Drop water out soleplate M33 - Burns or scorches clothes M34 - Bad gliding M35 - Scaling soleplate / boiler M36 - Brown spots / stains on the clothes M37 - Difficult to fill M38 - Condensation M39 - Soleplate stain, cannot be cleaned M3A - White particles come out of base / soleplate M3B - Does not remove wrinkles M3C - Appliance too heavy M3D - Printing wears off M3E - Handle sharp edges M3F - Insufficient smoothing M3X - Other "ironing / poor performance" problem	M40 - Noise / Unstable M41 - Unstable table M42 - Unstable iron M4X - Other "noise / unstable" problem	M50 - Leakage M51 - Water leakage M52 - Steam leakage M53 - Water runs out of water tank M54 - Steam leaks from the generator M55 - Water drips from ironing board M56 - Water runs out of generator M57 - Water-/ damp leakage on damp hose M5X - Other "leakage" problem	M60 - Damaged parts M61 - Damage on the soleplate M62 - Iron housing crack M63 - Generator housing crack M64 - Water tank crack M65 - Soleplate coating peel off/wear M66 - Steam hose/hose-cord damaged/frayed M67 - Damaged Collar clamp M68 - Damaged Button bar clamp M6X - Other damaged parts" problem					
				K L M N O P Q R S T U V	N BEVERAGE	N10 - No function N11 - No cold drink N12 - No hot drink N13 - Grinder does not work N14 - Pump doesn't work N15 - The coffee does not flow N16 - No gas / bubble N17 - Capsule or disk does not fit N18 - No milk froth production N1X - Other "no function" problem	N20 - Operational problem N21 - Time too long N22 - Insufficient froth N23 - Too much froth N24 - Pressure too high N25 - Pressure too low N26 - Problem with descaling program N27 - Problem with cleaning program N28 - Problem with combi program (cleaning and descaling) N29 - Beverage outlet instable N2A - Milk froth outlet instable N2B - Reverse liquid in water tank N2C - Scaling N2D - Wrong volume dispensed N2E - Problem with filter holder N2F - Overflowing N2G - Splashing N2H - Dripping N2X - Other "operational problem"	N30 - Beverage / poor performance N31 - Bad taste beverage N32 - Coffee powder in cup or coffee pot N33 - Bad grinding N34 - Drip tray full too fast N35 - Coffee too thin N36 - Coffee too strong N37 - Coffee powder in appliance N38 - Coffee pomace too muddy N39 - Incorrect bubbling N3A - Milk not hot enough (Milk preparing accessory) N3B - Mixed drink too cold N3C - Milk froth too cold N3D - Insufficient milk froth consistency N3E - Insufficient coffee cream N3F - Incorrect mixed beverage N3X - Other "beverage / poor performance" problem		N50 - Beverage leakage N5X - Other "beverage leakage"				
						X	P POWER TOOLS / GARDENING	P10 - No function P11 - No hammer P12 - No impact P13 - No brake P14 - No cutting P15 - No mulching P1X - Other "no function" problem	P20 - Operational problem P21 - Insufficient impact P22 - Insufficient pressure P23 - Insufficient brake P24 - Poor Bit holding P25 - Clutch blocking P26 - Chuck problem P2X - Other "operational problem"	P30 - Tools / poor performance / results P31 - Slanted cutting P3X - Other "tools / poor performance / results" proble			P60 - Damaged parts P61 - Battery extraction problem P62 - Blade problem P63 - Reflector problem P64 - Damaged case P65 - Valve problem P6X - Other damaged parts" problem	

Sectioncodes

COMMON		DATA OPERATION- AND PC-RELATED		GENERAL WG		WASHING / DRYING	
ANT	Antenna section	CIP	CI+ / CAM	G00	Whole product without defect	W01	Regeneration valve
APR	Signal processing (analog)	DKS	Docking station or port replicator	G01	Control / Front / top panel	W02	Water dispenser / Side tank / IWMS (Integrated Washing Management System)
BCH	Battery charging section	FMW	Firmware	G02	Knob / button (pop in/out)	W03	Detergent compartment / Detergent/Rinse aid dispenser
CLK	Clock / timer section	IDE	IDE interface section	G03	Bezel / disc	W04	Water softening device
CTR	Control panel	ILN	i.Link (IEEE1394 / Firewire) section	G04	Timer/Programmer / Main switch	W05	Overflow protection device
DEN	Decoder / Encoder section	ISA	ISA section	G05	Selector switch	W06	Level container
DPR	Signal processing (digital)	JST	Joystick / Navigation interface	G06	Indicating lamps/ Clock Display	W07	Circulation pump
EEP	EEProm section	KBD	Keyboard (separate)	G07	Indicator lamps / LED	W08	Drain/Outlet pump
ERA	Erase circuit	MCD	Memory Card section	G08	Wiring	W09	Tachometer / Circulation pump
FLX	Flexible printed circuit board	MDM	Modem section	G09	Terminal	W10	Upper/Lower spray arm
HFS	High frequency section (RF)	MEM	Memory circuit	G10	Mains suppressor	W11	Bearings / Bearing seal
IDS	Information display section	NIF	Network interface (wired)	G11	Timer	W13	Drum Tub
IFC	IF circuit	PAR	Parallel port	G12	Main control PCB / Circuit board / Control panel	W14	Door positioning device
INP	Signal input section	PCC	PC card	G13	Motor control PCB / Main circuit board	W15	Boot gasket
IRD	Infrared (IrDA) section	PCI	PCI section	G14	Push button / Fast freeze switch / Programmer selector switch	W16	Transport protection
OUT	Signal output section	SCS	SCSI port	G15	Push button on/off / Main switch / Touch panel/PCB		
PRG	Programming section	SDR	Software device driver / patch	G16	Microswitch	COOLING	
PRT	Protection circuit	SER	Serial port	G17	Door/Lid switch	C01	Fridge compressor
PSP	Power supply primary	SWA	Software application / APP	G18	Heating element / Upper grill element / Browner	C02	Freezer compressor
PSS	Power supply secondary	SWO	Software operating system	G19	Lower (base element)	C03	Fridge evaporator
PSU	Power supply	USB	USB port	G20	Defrost heater	C04	Freezer evaporator
PWA	Power amp section	WLS	Wireless / Bluetooth controller unit	G21	Heating element / Dry heating element / Anti-condensation heater	C05	Freezer / Fridge system
REM	Remote control section			G22	Motor	C06	Capillary tube
RFU	Booster / RF unit	MECHANICAL		G23	Starting device , Capacitor	C07	Dryer
SET	Total product	ARM	Arm mechanism	G24	Motor overheat/overload protection	C08	Service tube
SFT	Medium / Software (tape / disc / etc.)	BZL	Bezel	G25	Cooling fan assembly / Fan motor	C09	Lockring connector
SNS	Sensor unit	CBT	Cabinet	G26	Warm air fan motor / Cooling motor fan blade	C10	Fridge thermostat
SVO	Servo section	CDS	CD drive mechanism	G27	Tub / Inner liner / Container/inner casing / oven cavity	C11	Freezer thermostat
SYS	System control / Logic section	CHA	Chassis	G28	Insulation thermal / acoustic	C12	Defrost thermostat
TUN	Tuning section	CHG	Changer section	G29	Front/right counterweight	C13	Thermometers
TXT	Text processing	DDM	Disc drive mechanism	G30	Tub/Door seal / Gasket	C14	Icemaker with parts
WIR	Lead wire	DVD	DVD drive mechanism	G31	Shock absorber, Spring	C15	Drain heater
		EXC	External connector	G32	Hose tub/pump & Softener/Sump hose	C16	Drink dispenser
SOUND-RELATED		FAN	Fan / cooling	G33	Water system / Hoses	COOKING	
APA	Audio processing (analog)	FDD	Floppy disc drive	G34	Filter/Manifold / Outlet filter	H01	Cut out switch / Thermal cut out /
APD	Audio processing (digital)	FXT	Fixation section	G35	Condenser / Dry condenser duct	H02	Hob panel / glass
HPN	Headphone unit	HCM	Head carriage mechanism	G36	Water inlet valve	H03	Tap gas
MIC	Microphone section	HDD	Hard disc drive	G37	Inlet hose	H04	Feeding gas
SPK	Speaker	HOL	Cassette holder	G38	Drain/Outlet hose / Drip channel / tube	H05	Injector gas
VBR	Vibrator section	INC	Internal connector	G39	Non return valve	H06	Oven Gas burner
PICTURE-RELATED		INK	Ink unit	G40	Thermostats	H07	Radiant hot plate
CAM	Camera circuit	LDG	Loading mechanism	G41	Level control device	H08	Inductor
CPA	Colour processing (analog)	LNM	Lens mechanism	G42	Gas burner (except oven cavity burner)	H09	Inner glass
CPD	Colour processing (digital)	MDS	MD drive mechanism	G43	Gas ignition device	H10	Middle glass
CRT	Picture display	MIR	Mirror section	G44	Thermocouple	H11	Upper grill canopy
DDC	Display Drive circuit	OPU	Optical pick-up unit	G45	Casing/Cabinet with parts / Side panel	H12	Tray / Broil pan
DFH	Deflection horizontal	PCS	Paper cassette	G46	Side panel	H13	Rotisserie motor
DFL	Deflection circuit	PFM	Paper feed mechanism	G47	Base/Bottom frame / Casing/wrapper / Housing / Body	H14	Catalyst
DFV	Deflection vertical	PIN	Pinch roller / lever	G48	Feet/roller feet / wheel	H15	Magnétron
FPK	Focus pack	PRI	Print block / drum	G49	Top panel / Upper cover panel	H16	Diode high voltage
HDR	Horizontal drive	PUD	Pick-up device (analog)	G50	Door and door parts / lid / Glass / Outer glass	H17	Capacitor high voltage
IMG	Image display unit	RFM	Ribbon feed mechanism	G51	Freezer comp. door w. hinge / Inside of door / Gate	H18	Transformer low voltage
LCD	LCD section	RHD	Rotary head(s)	G52	Trim frame	H19	Transformer high voltage
LMP	Lamp / flash section	SCN	Scanning section	G53	Hinge	H20	Strier
VPA	Video processing (analog)	SHD	Stationary head(s)	G54	Door rack/Shelf	H21	Noise filter
VPD	Video processing (digital)	SLD	Sled mechanism	G55	Baskets/Racks / Detergent drawer/box	H22	Protector of waves
STA	Static block	SHU	Shutter Section	G56	Handle	GARMENT CARE	
VWF	Viewfinder	SRS	Supply reel section	G57	Glass/plastic/Wire shelves & Flap trim	S01	Soleplate
PRINTING/SCANNING MECHANISM		TCH	Touchpad / Touchscreen unit	G58	Evaporator tray	S02	Steam valve
ADU	Document holder section	TDM	Tape drive mechanism	G59	Basket guide rails/runner	S03	Water spray / steam spray
ASF	Document Feeder Section (external)	THR	Threading mechanism	G60	Installation problem	S04	Ironing board
CON	Consumable/Supply Section	TNR	Tension regulator	G61	Wrong usage	S05	Steam cord
DVS	Development Section	TPT	Tape path	G62	Instruction for use	FLOOR CARE	
FUS	Fixation/Fusing	TRS	Take-up reel section	G63	Lighting	F01	Bag
MCF	Manual Feeder	XXX	Cabinet / cosmetic parts	G64	Accessories	F02	Butt
PRO	Print Processing			G65	Fuse	F03	Hosepipe
SOF	Sorter/Finisher			G66	Finger / Hook lock of door	F04	Weigh modulate
				G67	Weigh modulate	F05	Nozzle
				G68	Battery charger / transformer	F06	Tube
				G69	Battery	F07	Communication interface
				G70	Tank	F08	Base station
				G71	Mechanical pump	F09	Movement sensor
				G72	Electrical pump	F09	Camera
				G73	Cord winder	BEVERAGE	
				G74	Safety valve	B01	Filter holder
				G75	Power supply cord	KITCHEN APPLIANCE / FOOD PROCESSING	
				G76	Cap	K01	bread carrier
				G77	Boiler	K02	grill plate
				G78	Nozzle	K03	bunwarmer
				G79	Pressure clamp / jaw	PERSONAL CARE / HEALTH CARE	
				G80	Distributor	P04	Cutting block
				G81	Lid	P05	Removal of hair block
				G82	Mil	P06	Laser
				G83	Remote	P07	Lamp
				G84	Knife / grater / blade / mixing blade	BABY CARE	
				G85	Transmission / pulley / driving belt / pinion	M01	Element ultra sonic
				G86	Jack	M02	Transmitter radio / TV
				G87	Pot / jug / bowl	M03	Receiver radio / TV
				G88	Cooling module	POWER TOOLS / GARDENING	
				G89	Solenoid valve	T01	Chuck
				G90	Software	T02	Gearbox
				G91	Packaging		
				G92	Lower cover panel		



EXTENDED CONDITION CODES

X11	At door
X12	At washing chamber
X13	At filter section
X14	At drawer
X15	At input section
X16	At output section
X17	At upper side
X18	At lower side
X19	At front side
X1A	At rear side
X1B	At left side
X1C	At right side
X1D	At inner side
X1E	At outer side
X1F	At back left
X1G	At back middle
X1H	At back right
X1J	At front left
X1K	At front middle
X1L	At front right
X1X	Other specific location
X21	During filling
X22	During prewashing
X23	During prerinsing
X24	During washing / cleaning
X25	During heating
X26	During rinsing
X27	During postrinsing / clearrinsing
X28	While pumping out
X29	When spinning during washing
X2A	During final spinning
X2B	During drying
X2C	While drum is turning
X2D	While drum is stopped
X2E	While taking water
X2F	During soaking program
X2X	Other specific point in washing dishwashing program or operation
X31	While opening or closing the door or tray
X32	During oven operation
X33	During microwave operation
X34	During hot plate operation
X35	During roasting
X36	During baking
X37	During grilling
X38	During self-cleaning
X3X	Other specific point in cooking program or operation
X41	During ice making / crushing
X42	During water dispensing
X43	During superfrost
X44	During defrosting
X45	During cooling
X46	While running fan
X47	During compressor stopped
X4X	Other specific point in refrigerator / freezer problem or operation

Defectcodes

MECHANICAL		ELECTRICAL	
A	Worn out (or general mechanical defect)	G3	Sharp Edges
A1	Malfunction	H	Cracked / peeled / corroded / melted
B	Dirty / clogged	H1	Cracked / peeled
C1	Too wide	H2	Corroded
C2	Too narrow	H4	Paint / colour mismatch
D	Cut / broken	I	Loose / off / stripped
D1	Split / torn	I1	Not welded or glued / broken weld
D2	CRT broken neck	I2	Loose parts in tube (visible or not)
E	Deformed	J	Shaky / unstable
F	Snapped	J1	Set not levelled properly
F1	Stuck / jammed	J2	Vibrating
F2	Tight	K3	CRT leak (no vacuum)
F4	Kinked / bent / squeezed	L	Dry (no lubricant)
G	Scratched / dented / sharp edges	M1	Blocked / clogged
G1	Display, scratches or external damage	O	Burnt / arcing / missing pixels
G2	Dented	V	Cracked printed circuit board
G3	Sharp Edges		
ELECTRICAL		REPAIRCODES	
16	Map data error	R1	CRT / Display open circuit
2	Exhausted / low emission	S	Leaking (electrical)
51	Faulty mains voltage	S1	CRT leaking (electrical)
N	Defective electrical component / module	T	Bad contact / connection
O1	CRT geometry out of spec	T1	Bad earth connection
O2	CRT convergence out of spec	U	Open pattern
O3	CRT focus defective	W	Cold or no soldering [NO LONGER USED]
O4	CRT / Display purity problem	W1	Missing solder
O5	CRT EHT (High Voltage) shortcircuit	W2	Bridged soldering
O6	CRT EHT (High Voltage) flashover	W3	Cracks in solder
O7	Out-of-spec pixel defects in display	W4	Solder did not stick to component
O8	Deflection coil defective	W5	Component did not contact solder
O9	Noise from CRT / Display or deflection coil	W6	Lead wire / flat cable is bent / wrong component position
Q	Short circuit	X	Bridged soldering
Q1	CRT / Display short circuit	Y	Wrong component / module
R	Open circuit	Z	Missing component / module
R1	CRT / Display open circuit		
1	Software correction / reset	N	Maintenance
11	Formatted	O	Refurbishing / reconditioning
2	Software upgrade	P	Preventive parts replacement
3	Product upgrade (on request)	Q	Preventive action without parts replacement
4	Remote resolution	Q1	Preventive software update
41	Remote resolution by interaction with enduser	R1	Return / reimbursement (repair too expensive)
42	Remote resolution by connection to the product	R2	Return / reimbursement (too many visits / repairs)
A	Component Replacement	R3	Return / reimbursement (parts not available)
A1	Refilling	R4	Return / reimbursement (impossible to repair)
A2	Module replacement	R5	Return / reimbursement (on request of retailer)
AF	Free of cost part	R6	Return / reimbursement (on request of manufacturer)
AN	New defective part	R7	Return / reimbursement (commercial agreement)
AR	Replacement with a refurbished component	R8	Return / reimbursement (spare part exhausted)
AX	Replacement by a scrap component	R9	Return / reimbursement (spare part not created)
B	Mechanical alignment	U	Explanation for customer
C	Electrical alignment	V	Cost estimation refused
C1	Software adjustment by internal service menu	W	Cost estimation with parts
C2	Software adjustment by external service tool	X	Cost estimation without parts
C3	Firmware recovery	Y	Return without repair
C4	Data Backup and Restore	Y1	Scrapped
C5	Calibration	Y2	Scrapped with refund
D	Resoldering	Y3	Product transport / forwarding
D1	Refitting / putting back in position (connector / tube ...)	Y4	Product installation
D2	Welding	Z	Set exchange
E	Cleaning	Z0	Product exchange (commercial agreement)
F	Lubrication	Z1	Product exchange (repair too expensive)
G	Repaired electrical parts	Z2	Product exchange (too many visits / repairs)
H	Repaired mechanical parts	Z3	Product exchange (parts not available)
I	Modification requested by manufacturer	Z4	Product exchange (impossible to repair)
I1	Setup for gas	Z5	Product exchange (on request of retailer)
J	Removed	Z6	Product exchange (on request of manufacturer)
K	Added	Z7	Product accessory exchange
L	Functional check	Z8	Product exchange (spare part exhausted)
M	Specification measurement	Z9	Product exchange (spare part not created)
N	Maintenance		

	1 - PRODUCT	2 - PERIPHERALS / MEDIA	3 - CUSTOMER PERCEPTION / DOCUMENTATION	4 - CONNECTIVITY	5 - SERVICE PROVIDER
1 INSTALL & SETUP	111 - Difficulty with initial tuning 112 - Difficulty tuning TV to VCR 113 - Difficulty mapping, naming or storing channels 11X - Other difficulty with Product setup	121 - No battery fitted 122 - Incorrect battery used 123 - Battery installed incorrectly 124 - Incorrect Power Supply used 125 - Power supply connected improperly 126 - Incorrect Accessory used 12X - Other difficulty with peripherals / media setup	131 - Customer did not read "Quick Start" guide 132 - Customer did not read Instruction Manual 133 - Wrong explanation in Instruction Manual 134 - Confusing Technical Specification 13X - Other setup problem related to customer perception / documentation	141 - Not properly connected to aerial 142 - VCR not properly connected to TV 143 - Surround sound system not properly connected 144 - Incorrect antenna used 145 - Incorrect connection lead used 14X - Other setup problem related to connectivity	151 - Customer not registered with provider 15X - Other setup problem related to provider
2 LOCAL CONDITIONS	211 - Operating under extreme temperature / humidity conditions 212 - Operating under extreme lighting conditions 213 - Operating under adverse background noise 214 - Mains voltage out of spec 21X - Other local conditions affecting the product	221 - Battery discharged 222 - Interference from peripheral equipment connected / not connected 223 - Remote used out of workable area 22X - Other local conditions affecting peripherals / media	231 - After checking symptom not found	241 - Poor signal strength in area 242 - Equipment outside service area 243 - Signal interference connected / not connected 244 - Incorrect location of surround speakers 245 - Bad antenna installation 24X - Other local conditions affecting reception / operation	251 - No PDC / VPS / ShowView service available 252 - No NICAM / Stereo service available 253 - No Widescreen service available 254 - No RDS service available 255 - No DAB/DVB service available 25X - Other missing service
3 COMPLEXITY	311 - Confusing layout of user controls on set 312 - User controls on set too small to operate 313 - Poor markings on user controls / connections 314 - Poor/ confusing info on display 31X - Other problem due to operational complexity of set	321 - Confusing layout of user controls on remote 322 - User controls on remote too small to operate 32X - Other problem due to operational complexity of peripheral	331 - Difficulty operating the set 332 - Difficulty operating the remote commander 333 - Difficulty operating Timer recording 334 - Difficulty operating Teletext 335 - Difficulty setting the clock	341 - SCART lead not connected - No AV channel 342 - Supplied lead connected incorrectly 343 - Incorrect use of digital connection 344 - Incorrect IEEE1394 connection 34X - Other problem due to complexity of connections	
4 SOFTWARE / QUALITY	411 - Software incompatibility with customer product 412 - Customer lost Password / Access code	421 - Poor quality storage medium used 422 - Damaged storage medium used 423 - Incorrect format medium used	431 - Product does not meet customer expectation 432 - Picture quality does not meet customer expectation 433 - Audio quality does not meet customer expectation 434 - Cosmetic quality does not meet the customer expectation 435 - Noise level does not meet customer expectation	441 - Software incompatibility with other product 442 - Signal incompatibility with other product	451 - Incorrect software version

NOTE: IN CASE OF A NON-TECHNICAL FAULT, THE NON-TECHNICAL FAULT CODE MUST BE ENTERED IN THE LOCATION FORESEEN FOR THE SECTION CODE

Extended Symptomcodes

www.iriscode.org



DIGITALEUROPE



LOCATION		VARIOUS		VARIOUS		VARIOUS		VARIOUS			
L - LOCATION		VT - Time / Colour		VC - Battery / Consumption material		VP - Physical Environment		VS - Situation			
		VT1	MORNING	VC1	NICD BATTERY	VP1	EXTREME HEAT	VS1	INSIDE	VF1	ERROR CODE
		VT2	NOON	VC2	NIMH BATTERY	VP2	EXTREME COLD	VS2	OUTSIDE	VF2	OPERATION TIME
		VT3	AFTERNOON	VC3	LITHIUM ION BATTERY	VP3	EXTREME HUMIDITY	VS3	AT THE BEACH	VF3	INSTALLATION DATE
		VT4	EVENING	VC4	LITHIUM BATTERY	VP4	EXTREME DRY	VS4	IN THE MOUNTAINS	VF4	SOFTWARE VERSION
		VT5	NIGHT	VC5	ALKALINE BATTERY	VP5	HIGH PRESSURE	VS5	UNDER WATER	VF5	PRODUCTION DATE/CODE
		VT6	SPRING	VC6	ZINC-AIR BATTERIES	VP6	LOW PRESSURE	VS6	IN AN AIRPLANE	VF6	CHANNEL
		VT7	SUMMER	VC7	MERCURY BATTERY	VP7	HIGH SPEED	VS7	ON A BOAT	VF7	FREQUENCY
		VT8	AUTUMN	VC8	PB BATTERY	VP8	LOW SPEED	VS8	IN A TRAIN	VF8	SPECIFIC MEDIUM TYPE
		VT9	WINTER	VC9	PRODUCT SPECIFIC BATTERY	VP9	AT HIGH POWER / VOLTAGE	VS9	IN A CAR	VF9	RELATED KEY
		VTa	WHITE	VCa	INK COLOUR	VPb	AT LOW POWER / VOLTAGE	VSa	ON A (MOTOR)BIKE	VFa	COMPONENTS ID NUMBER
		VTb	BLACK	VCb	INK BLACK	VPc	HIGH NOISE LEVEL	VSb	USED IN FOREIGN COUNTRY	VFb	MODIFICATION TYPE
		VTc	RED	VCc	TONER	VPe	LOW NOISE LEVEL	VSd	AT THE BEGINNING	VFc	RELATED MENU ITEM
		VTd	GREEN	VCd	THERMAL TRANSFER FOIL	VPf	SILENCE	VSd	AT THE END	VFd	RELATED OPERATION / MODE
		VTe	BLUE	VCe	THERMAL TRANSFER PAPER	VPg	MUSIC	VSf	WHILE DRIVING	VFf	CAR VEHICLE ID
L10	TOP LEFT	VTf	YELLOW	VCf	FILTER	VPH	SPEECH	VSf	WHILE WALKING	VFf	MILEAGE / KILOMETRE COUNT
L20	TOP MIDDLE	VTg	MAGENTA	VCg	BAG	VPi	SMALL ROOM	VSg	WHEN NOT MOVING	VFg	OPERATING DISTANCE
L30	TOP RIGHT	VTg	MAGENTA	VCg	BAG	VPj	LARGE ROOM	VSg	WHEN OPEN	VFh	VALUE / LEVEL OF SETTING
L40	CENTER LEFT	VTi	PINK	VCi	PAD	VPk	DIRTY ENVIRONMENT	VSi	WHEN CLOSE	VFf	VOLTAGE
L50	CENTER MIDDLE	VTj	CYAN	VCj	BLADE	VPk	CLEAN ENVIRONMENT	VSj	EXCESSIVE USING	VFj	CONSUMPTION
L60	CENTER RIGHT	VTk	LIGHT	VCk	LAMP	VPm	SMOKED ENVIRONMENT	VSj	LOW / RARE USING	VFk	MEASUREMENTS / DIMENSIONS
L70	BOTTOM LEFT	VTl	DARK	VCl	FOIL	VPn	ORIGINAL PACKING	VSd	PROFESSIONAL USING	VFd	VOLUME / CAPACITY
L80	BOTTOM MIDDLE	VTm	n/a	VCm	n/a	VPo	FOREIGN PACKING	VSd	UNUSED	VFm	PAGE NUMBER
L90	BOTTOM RIGHT	VTn	n/a	VCn	n/a	VPp	FULL	VSd	UNPACKED	VFm	BRAND NAME
LdL	DIAGONAL LINE FROM LEFT TOP	VTn	n/a	VCn	n/a	VPq	EMPTY	VSd	PROBLEM WITH SELF RECORDED	VFo	MODEL NAME
LdR	DIAGONAL LINE FROM RIGHT TOP	VTp	n/a	VCp	n/a	VPq	FILLING 10% - 30%	VSd	PROBLEM WITH PRE RECORDED	VFp	BOOT COUNT
LxX	OTHER	VTq	n/a	VCq	n/a	VPs	FILLING 40% - 60%	VSd	PROBLEM AT AUTO START	VFq	n/a
		VTq	n/a	VCq	n/a	VPs	FILLING 40% - 60%	VSd	PROBLEM AT AUTO START	VFq	n/a
		VTr	n/a	VCr	n/a	VPt	FILLING 70% - 90%	VSd	PROBLEM AT MANUAL START	VFr	n/a
		VTr	n/a	VCr	n/a	VPt	FILLING 70% - 90%	VSd	PROBLEM AT MANUAL START	VFr	n/a
		VTs	n/a	VCs	n/a	VPu	USED IN STONE HOUSE / WALL	VSd	AFTER SETUP / INSTALLATION	VFs	n/a
		VTT	n/a	VCT	n/a	VPv	USED IN WOODEN HOUSE / WALL	VSd	AT REMOTE OPERATION	VFT	n/a
		VTU	n/a	VCU	n/a	VPw	n/a	VSu	AFTER CLEANING	VFU	n/a
		VTU	n/a	VCU	n/a	VPw	n/a	VSu	AFTER CLEANING	VFU	n/a
		VTV	n/a	VCV	n/a	VPy	n/a	VSv	DOWNLOAD	VFV	n/a
		VTW	n/a	VCW	n/a	VPz	n/a	VSv	UPLOAD	VFw	n/a
		VTX	OTHER	VCX	OTHER	VPx	OTHER	VSx	OTHER	VFX	OTHER

NOTICE: USE OF EXTENDED IRIS CODES IS OPTIONAL AND DEPENDS ON COMPANY REQUIREMENTS.


BASIC PRINCIPLE OF EXTENDED IRIS CODES

1. BASIC USE

BASICALLY THE "SECTION CODE" FIELD CAN BE USED FREELY TO ENTER EITHER:


- "STANDARD" (TECHNICAL) IRIS SECTION CODES
- "NON-TECHNICAL FAILURE" (NTF) CODES
- SIMPLE THREE_BYTE EXTENDED CONDITION CODES

(DUE TO THEIR DIFFERENT BASIC STRUCTURE, COMMON CODES THAT MIGHT CREATE CONFUSION WILL NOT EXIST)



2. ADVANCED USE

A "STANDARD" IRIS LINE IN WHICH THE CONDITION CODE CONTAINS THE LETTER "X" IS CONVERTED INTO AN "EXTENDED" IRIS LINE.



BASIC SCREENLOCATION MATRIX

BASIC MATRIX		
10	20	30
40	50	60
70	80	90

DETAILED MATRIX								
11	12	13	21	22	23	31	32	33
14	15	16	24	25	26	34	35	36
17	18	19	27	28	29	37	38	39
41	42	43	51	52	53	61	62	63
44	45	46	54	55	56	64	65	66
47	48	49	57	58	59	67	68	69
71	72	73	81	82	83	91	92	93
74	75	76	84	85	86	94	95	96
77	78	79	87	88	89	97	98	99

L10	TOP LEFT	L30	TOP RIGHT	L50	CENTER MIDDLE	L70	BOTTOM LEFT	L70	BOTTOM RIGHT		
L11	TOP LEFT L11	L31	TOP RIGHT L31	L51	CENTER MIDDLE L51	L71	BOTTOM LEFT L71	L71	BOTTOM RIGHT L91	LH1	HORIZONTAL LINE AT 11
L12	TOP LEFT L12	L32	TOP RIGHT L32	L52	CENTER MIDDLE L52	L72	BOTTOM LEFT L72	L72	BOTTOM LEFT L72	LH2	HORIZONTAL LINE AT 14
L13	TOP LEFT L13	L33	TOP RIGHT L33	L53	CENTER MIDDLE L53	L73	BOTTOM LEFT L73	L73	BOTTOM LEFT L73	LH3	HORIZONTAL LINE AT 17
L14	TOP LEFT L14	L34	TOP RIGHT L34	L54	CENTER MIDDLE L54	L74	BOTTOM LEFT L74	L74	BOTTOM LEFT L74	LH4	HORIZONTAL LINE AT 41
L15	TOP LEFT L15	L35	TOP RIGHT L35	L55	CENTER MIDDLE L55	L75	BOTTOM LEFT L75	L75	BOTTOM LEFT L75	LH5	HORIZONTAL LINE AT 44
L16	TOP LEFT L16	L36	TOP RIGHT L36	L56	CENTER MIDDLE L56	L76	BOTTOM LEFT L76	L76	BOTTOM LEFT L76	LH6	HORIZONTAL LINE AT 47
L17	TOP LEFT L17	L37	TOP RIGHT L37	L57	CENTER MIDDLE L57	L77	BOTTOM LEFT L77	L77	BOTTOM LEFT L77	LH7	HORIZONTAL LINE AT 71
L18	TOP LEFT L18	L38	TOP RIGHT L38	L58	CENTER MIDDLE L58	L78	BOTTOM LEFT L78	L78	BOTTOM LEFT L78	LH8	HORIZONTAL LINE AT 74
L19	TOP LEFT L19	L39	TOP RIGHT L39	L59	CENTER MIDDLE L59	L79	BOTTOM LEFT L79	L79	BOTTOM LEFT L79	LH9	HORIZONTAL LINE AT 77

L20	TOP MIDDLE	L40	CENTRE MIDDLE	L60	CENTRE RIGHT	L80	BOTTOM MIDDLE	LV1	VERTICAL LINE AT 11
L21	TOP MIDDLE 21	L41	CENTRE MIDDLE 41	L61	CENTRE RIGHT 61	L81	BOTTOM MIDDLE 81	LV2	VERTICAL LINE AT 12
L22	TOP MIDDLE 22	L42	CENTRE MIDDLE 42	L62	CENTRE RIGHT 62	L82	BOTTOM MIDDLE 82	LV3	VERTICAL LINE AT 13
L23	TOP MIDDLE 23	L43	CENTRE MIDDLE 43	L63	CENTRE RIGHT 63	L83	BOTTOM MIDDLE 83	LV4	VERTICAL LINE AT 21
L24	TOP MIDDLE 24	L44	CENTRE MIDDLE 44	L64	CENTRE RIGHT 64	L84	BOTTOM MIDDLE 84	LV5	VERTICAL LINE AT 22
L25	TOP MIDDLE 25	L45	CENTRE MIDDLE 45	L65	CENTRE RIGHT 65	L85	BOTTOM MIDDLE 85	LV6	VERTICAL LINE AT 23
L26	TOP MIDDLE 26	L46	CENTRE MIDDLE 46	L66	CENTRE RIGHT 66	L86	BOTTOM MIDDLE 86	LV7	VERTICAL LINE AT 31
L27	TOP MIDDLE 27	L47	CENTRE MIDDLE 47	L67	CENTRE RIGHT 67	L87	BOTTOM MIDDLE 87	LV8	VERTICAL LINE AT 32
L28	TOP MIDDLE 28	L48	CENTRE MIDDLE 48	L68	CENTRE RIGHT 68	L88	BOTTOM MIDDLE 88	LV9	VERTICAL LINE AT 33
L29	TOP MIDDLE 29	L49	CENTRE MIDDLE 49	L69	CENTRE RIGHT 69	L89	BOTTOM MIDDLE 89		